

Packing List

In addition to this guide, the package includes the following items:

IoTstar2025-RCxxx
Sxxx-xxxx-xxxx-xxxx

Serial number sticker is affixed to
the cardboard inside the package

Technical Support

service@icpdas.com


www.icpdas.com

iotstar.icpdas.com

Resources

How to search for drivers, manuals and spec information on ICP DAS website.

- For Mobile Web



- For Desktop Web




1 Install IoTstar software


Please refer to "2 System Installation and Setting" chapter of IoTstar 2025 User Manual to complete the IoTstar 2025 software installation.

2 Register & get license file from IoTstar website

1. Go to IoTstar official website → **【 Download 】** page. Then click the "Registration" button to visit the registration page of IoTstar.




2. Fill in the user Information, serial number and Hardware ID, then click the "Getting License File for IoTstar" button. If the key-in information is correct, an email with the license file of IoTstar would be sent to your email account.




3 Complete the registration of IoTstar software

When you receive the license file of IoTstar 2025 you purchased, please follow the steps below to complete the license file binding for IoTstar 2025:


1. Click **【Start Menu】** → **【All apps】** → **【ICPDAS】** → **【IoTstar】** to open the IoTstar system interface.



2. Click the "License" button on the IoTstar system interface to open the License setting window. In the "License" setting window, click the "Browse..." button to find the location of the IoTstar license file.



3. If the license file is valid, and IoTstar 2025 has been successfully imported the license, the IoTstar 2025 you are using will be changed to the officially authorized version and the license setting page will also be updated simultaneously with the authorization information of this IoTstar 2025 (Number of controllers supported).




4 Login IoTstar system

Before login to IoTstar, users have to create a user account of IoTstar by the following steps:

1. Click the "Sign up now!" button.



2. Input your email address in the "Email" field and click the "Verification" button. IoTstar will send a verification email to this email address later. Check your mailbox and find the Verification email sent by IoTstar. Click the link in the email to complete the procedure of the email verification.



3. Key in the information, then click the "Submit" button. If the information is valid, the registration procedure of the new account will be completed. After the administrator activates this user account, user can click the "Login" button to visit IoTstar login page.

